



HELMET SIZING

JOE ROCKET

PROPER HELMET FITMENT

WARNING Never buy a used helmet or borrow someone else's helmet. Over time the protective foam in helmets will adjust to the contours of a user's head. A used or borrowed helmet may not offer as much protection as a new helmet.

WARNING Wearing the wrong size helmet can increase your risk of serious injury or death in an accident. A helmet that is too large for your head may be dislodged or knocked off in an accident. To select the right size helmet for your head, follow these instructions:

1. Measure your head. Wrap a tape measure around your head about one inch (2.5 cm) above your eyebrows.
2. Use the sizing chart to select the helmet size that corresponds most closely to your head measurement. If your head size falls between two helmet sizes, try on the larger helmet first and then the smaller size. Click here to see the sizing chart.
3. Try on the helmet by grasping both chin straps to pull the helmet completely onto your head, ensuring that the top of your head is in contact with the top of the helmet interior.
4. Check for a proper fit. To make sure your helmet is the right size, check that: **A.** The helmet inner lining fits snugly around your head. **B.** The top pad presses firmly on your head. **C.** The cheek pads contact your cheeks. **D.** There is no space around your brow under the inner lining.

Test this by trying to insert your fingers. If the helmet does not fit snugly, try on a smaller size.

5. Check your field of vision when trying on a helmet. Some helmets may obstruct or block your vision when looking left, right, up, or down.

Always make sure you can see well enough to safely operate your motorcycle.



6. TEST HELMET FIT

* Modular Helmets were designed to be used in the closed chin bar position, thus be sure all helmet "fitting" is done while chin bar is in the closed and locked position.

7. Fasten the retention system (chin strap) as tight as possible under your jaw without causing pain. There must be no slack in the strap, and the strap must be tight up against your jaw. Click to view the helmet retention system.



8. TEST CHIN STRAP

8. Test the retention system (chin strap)

Put your hands on the back of the helmet and try to push the helmet off by rotating it forward.

Put your hands on the front of the helmet above your forehead (or on the chin guard) and try to push the helmet off by rotating backward.

If helmet comes off, try another size or another model or brand.

Repeat steps 3 through 8 until you find a helmet that fits your head snugly and securely.

ADULT JOE ROCKET

SIZE	CENTIMETER	HAT SIZE	INCHES
XS	53 - 54	6 5/8 - 6 3/4	20 7/8 - 21 1/4
SM	55 - 56	6 7/8 - 7	21 5/8 - 22
MD	57 - 58	7 1/8 - 7 1/4	22 1/2 - 22 7/8
LG	59 - 60	7 3/8 - 7 1/2	23 1/4 - 23 5/8
XL	61 - 62	7 5/8 - 7 3/4	24 - 24 3/8
2XL	63 - 64	7 7/8 - 8	24 3/4 - 25 1/4

MEN'S SIZING

MENS LEATHER RACE SUIT

SIZE	38	40	42	44	46	48	50	52	54	56
CHEST	37-38	39-40	41-42	43-44	45-46	47-48	49-50	51-52	53-54	55-56
WAIST	29-30	30-32	30-34	32-36	34-38	36-40	38-42	40-44	42-46	44-48
SLEEVE	31	31	32	33	34	35	35	35	35	35
INSEAM	31	32	32	32	33	33	34	34	35	35
AP. WEIGHT	125-140	135-150	150-175	160-185	170-195	180-205	190-215	200-225	210-235	220-245
AP. HEIGHT	5'4"-5'10"	5'6"-5'10"	5'7"-6'1"	5'9"-6'1"	5'9"-6'2"	5'9"-6'2"	5'9"-6'2"	5'9"-6'2"	5'9"-6'2"	5'9"-6'2"

* Inseam measurements for suits run from crotch to above the ankle bone.

MENS SURVIVOR SUIT

SIZE	S	M	L	XL	2XL
CHEST	34-36	38-40	40-42	42-44	46-48
WAIST	26-28	29-31	32-34	34-36	36-39
SLEEVE	32	32	33	34	35
INSEAM REG	34	34	34	34	34
INSEAM SHORT	N/A	30.5	30.5	30.5	30.5

* Short sizes are 3.5" shorter on the inseam.

MENS JACKETS ALPHA

SIZES	XS	S	M	L	XL	2XL	3XL	4XL	5XL
CHEST	34-36	38-40	40-42	42-44	46-48	50-52	54-56	58-60	61-63
WAIST	26-28	29-31	32-34	34-36	36-39	39-42	42-45	45-49	49-53
SLEEVE	32	32	33	34	35	36	36.5	36.5	37

* For tall size jackets, add 2" to the sleeve length and 3" to the torso length.

MENS JACKETS NUMERICAL

SIZES	38	40	42	44	46	48	50	52	54	56
CHEST	38	40	42	44	46	48	50	52	54	56
WAIST	29	32	34	38	40	42	44	46	48	50
SLEEVE	32	33	33	34	35	35	36	36	36.5	36.5

* For tall size jackets, add 2" to the sleeve length and 3" to the torso length.

WOMEN'S SIZING

LADIES JACKETS

SIZES	XS	S	M	L	XL	2XL/1 DIVA	2 DIVA
BUST	31	33-34	35-36	37-39	40-42	42-44	45-48
WAIST	24-25	26-27	28-29	30-31	32-34	34-36	37-39
HIP	35-36	37-38	39-40	41-42	43-44	44-45	46-49

MENS SPEEDMASTER 5.0 PANT

SIZES	30	32	34	36	38	40	42
WAIST	30	32	34	36	38	40	42
INSEAM	30 7/8	31 1/4	31 5/8	32	32 3/8	32 3/4	33 1/8

MENS BLASTER 2.0 PANT

SIZES	30	32	34	36	38	40	42
WAIST	30	32	34	36	38	40	42
INSEAM	30 7/8	31 1/4	31 5/8	32	32 3/8	32 3/4	33 1/8

MENS ALTER EGO 2.0 PANT

SIZES	S	M	L	XL	2XL	3XL
WAIST	31-32	32-33	34-35	35-38	38-41	41-44
INSEAM REG.	32	32	32	32	32	32
INSEAM TALL.	N/A	34	34	34	34	34

LADIES CLEO PANT

SIZES	XS	S	M	L	XL
WAIST	26-27	28-29	30-31	32-33	34-35
HIP	36-37	38-39	40-41	42-43	44-45
INSEAM	32	32	32	32	32

MENS ATOMIC PANT

SIZES	S	M	L	XL	2XL
WAIST	31-32	32-33	34-35	35-38	38-41
INSEAM	34	34	34	34	34

LADIES ALTER EGO PANT

SIZES	XS	S	M	L	XL	2XL
WAIST	26-27	28-29	30-31	32-33	34-35	36-37
HIP	36-37	38-39	40-41	42-43	44-45	46-48
INSEAM *	35	35	35	35	35	35

*Height adjustable hem. Adjusts to 31", 33" or 35"

MENS PRO STREET PANT

SIZES	30	32	34	36	38	40	42
WAIST	30	32	34	36	38	40	42
INSEAM REG.	33	33 1/2	33 3/4	34 1/4	34 3/4	35	35 1/2

MENS BALLISTIC 7.0 PANT

SIZES	S	M	L	XL	2XL	3XL	4XL	5XL
WAIST	30-31	32-33	34-35	35-38	38-41	41-44	45-48	49-52
INSEAM Short	N/A	32	32	32	32	32	N/A	N/A
INSEAM Reg	34	34	34	34	34	34	34	34
INSEAM Tall	N/A	36	36	36	36	36	N/A	N/A

* For tall sizes, add 2" to the length and for short sizes subtract 2" to the length.

MENS PHOENIX 2.0 PANT

SIZES	S	M	L	XL	2XL	3XL	4XL	5XL
WAIST	30-31	32-33	34-35	35-38	38-41	41-44	45-48	49-52
INSEAM SHORT	N/A	30	30	30	30	30	N/A	N/A
INSEAM REG.	32	32	32	32	32	32	32	32

* For short sizes subtract 2" to the length.

MENS ROCKET DENIM JEANS

SIZES	30	32	34	36	38	40	42
WAIST	30	32	34	36	38	40	42
INSEAM SHORT	31 1/2	31 1/2	31 1/2	31 1/2	31 1/2	31 1/2	31 1/2
INSEAM REG.	33 1/2	33 1/2	33 1/2	33 1/2	33 1/2	33 1/2	33 1/2

JOE ROCKET

MEASURING INSTRUCTIONS

1. Chest - Measure the widest part of your chest, from under your armpits and around your back. Be sure arms are in a resting position on your sides.
2. Waist - Measure the smallest point of your waist.
3. Sleeve - Measure from the middle of the back of your neck, go over your shoulder, and over your elbow ending at your wrist.
4. Inseam - For 1 and 2 piece suits measure the inseam from the crotch to the top of the ankle. For all other pants measure the inseam from the crotch to the foot.
5. Hips - Measure around the fullest part of your body at the top of your leg.

NOTE: For best results, we suggest that measurements not be done over clothing.

