

INSTRUCTIONS:



DISCLAIMER:

* IF THE AREA OF APPLICATION IS NOT CLEAN, THE DECAL WILL NOT PROPERLY ADHERE TO THE SURFACE.

* AVOID CHEMICAL DEGREASERS SUCH AS SIMPLE GREEN, AS THEY WILL LEAVE A FILM ON THE PLASTIC WHICH WILL PREVENT YOUR GRAPHICS FROM STICKING TO YOUR BOOTS.

* THIS IS A VINYL PRODUCT; CONTACT WITH PHYSICAL OBSTACLES SUCH AS ROCKS, TREE BRANCHES, ETC., WHILE RIDING MAY CREATE CUTS AND TEARS IN THE GRAPHIC MATERIAL WHICH ARE NOT CONSIDERED TO BE PRODUCT DEFECTS.

* FOR BEST RESULTS, DO NOT APPLY STICKERS IN EXTREME HOT OR COLD TEMPERATURES.

INSTRUCTIONS:

1. PRIOR TO REMOVING GRAPHICS FROM SHEET, FAMILIARIZE YOURSELF WITH THE PLACEMENT OF THE DECALS, IN RELATION TO THE BOOT (DIAGRAM ABOVE). AS WITH ANY DECAL APPLICATION, IT IS VITAL TO BEGIN WITH A CLEAN SURFACE, WHICH IS FREE OF ANY DIRT, GREASE, OR GRIME. IN THE CASE OF NEW/UNUSED PLASTICS, STANDARD RUBBING ALCOHOL MAY SUFFICE FOR AREA PREPARATION, WHILE OLDER USED PLASTICS MAY NEED CLEANSING OR A SCRUB WITH WATER AND A SMALL DROP OF DISHWASHING LIQUID, FOLLOWED BY A RINSE, AND THEN RUBBING ALCOHOL. ALLOW CLEANSED AREA TO DRY THOROUGHLY, REMOVING ANY RESIDUAL LINT OR DUST FROM DRYING.

2. SELECT A GRAPHIC AND REMOVE IT FROM THE SHEET. STARTING AT ANY ONE SIDE, PLACE EDGE OF DECAL WHERE IT ALIGNS WITH THE CONTOURS OF THE BOOT.

3. SLOWLY LAY THE REST OF THE DECAL DOWN ON THE SURFACE, PRESSING DOWN GENTLY TO MAKE GOOD CONTACT WITH THE SURFACE, WHILE USING YOUR FINGERTIPS OR CREDIT CARD TO MOVE ANY AIR BUBBLES TO THE EDGE OF THE DECAL.

4. REPEAT AS NECESSARY AND THEN ADMIRE THOSE FRESH G'S ON YOUR FEET!