

## BRACE SIZES

TYKE		PRODIGY			
INCHES	24 - 28	INCHES	29 - 33		
CENTIMETERS	61 - 71	CENTIMETERS	74 - 84		
SMALL		MEDIUM		LARGE	
INCHES	33 - 36	INCHES	37 - 41	INCHES	42 +
CENTIMETERS	84 - 92	CENTIMETERS	94 - 104	CENTIMETERS	106 +

### HOW TO MEASURE BRACE SIZE

#### How to use the size guide:

- 1 - Print this page at 100% sizing. \*Do not scale the image down to fit your printer, the sizing will not be correct.
- 2 - Cut out the 5 sections.
- 3 - Use tape to join the 5 sections together, one by one. Line up the edges with each other as shown below.  
\*Do not overlap the pieces.




- 4 - Carefully wrap the size guide around your chest, just below the arms.
- 5 - The line on section one, labelled "0", will fall in one of the size areas... This is your size!

#### Additional sizing tips:

- Each size is labeled with "small adjustment | large adjustment". If you fall in the smaller half of the size, it is likely that you will want to run your brace on the smaller of its 2 settings, and if you fall in the larger half of the size, your brace may be better fitted with the larger adjustment setting.

- If you fall perfectly inbetween 2 sizes, you may be able to go either way. For kids that expect to grow quickly, we suggest opting for the larger size. For adults we recommend the smaller of the 2 sizes. The use of straps is also very highly recommended for all users.

For more info, please visit [www.atlasbrace.com](http://www.atlasbrace.com).



ATLAS BRACE SIZING

GUIDE

PLACE TAPE AROUND CHEST, JUST BELOW THE ARMS AND MEASURE.

TYKE

SMALL

LARGE

PRODIGY

MEDIUM

24" (61 cm)
29" (74 cm)
33" (84 cm)
36.5" (93 cm)

29"
33"
37"
41"

74 cm
84 cm
94 cm
104 cm

SMALL ADJUSTMENT | LARGE ADJUSTMENT
SMALL ADJUSTMENT | LARGE ADJUSTMENT
SMALL ADJUSTMENT | LARGE ADJUSTMENT
SMALL ADJUSTMENT | LARGE ADJUSTMENT